






CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1020-S

| | |
|--------------------------|---|
| Қисми рақамӣ: | CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1020-S |
| Истеҳсолкунанда / Бренд: | Schurter |
| Тавсифи Маҳсулот | SWITCH PUSH SPST-NO 100MA 42V |
| Маълумотнома: |  CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1020-S.pdf |
| Роҳнамо |  Пешниҳоди роғони / РОҶИ РОҶИ ЧАВОН |
| Гирифтани аз | Гонконг |
| Роҳи фиристодан | DHL/Fedex/TNT/UPS/EMS |

ДАРХОСТ БАРОИ ДАРХОСТ

Тасвир метавонад намояндагӣ бошад. Нигаред ба тафсилоти маҳсулот.













Хусусиятҳои CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1020-S

| | |
|---------------------------------------|---|
| ҚИСМИ РАҚАМӢ | CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1020-S |
| ИСТЕҲСОЛКУНАНДА | Schurter |
| ТАВСИФИ | SWITCH PUSH SPST-NO 100MA 42V |
| СТАТУСИ РОЙГОНИ РОЙГОН / СТАТУСИ ROHS | Пешниҳоди роғони / РОҶИ РОҶИ ЧАВОН |
| РӢЙХАТ |  CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1020-S.pdf |
| САТҶИ VOLTAGE - DC | 60V |
| САТҶИ ВОЛГА - AC | 42V |
| НАМУДИ | Capacitive, Illuminated |
| ТАРЗИ ҚАТӢ | Wire Leads |
| ФУНКСИЯРО ИВАЗ КУНЕД | Off-Mom |
| СИЛСИЛА | CPS |
| ТАФТИШИ АНДОЗАГИРИИ ПАНЕЛ | Circular - 16.10mm Dia |
| ПУРРА | Bulk |
| ҶАРОРАТ | -40°C ~ 60°C |
| НАВӢИ ТАВАЛЛУД | Panel Mount, Front |
| САТҶИ НОРАСОИИ НУРИҶО (MSL) | 1 (Unlimited) |
| ҶАӢТИ МЕХАНИКӢ | - |
| СТАТУСИ РОЙГОНИ РОЙГОН / СТАТУСИ ROHS | Lead free / RoHS Compliant |
| МУҲОФИЗАТИ ПӢСТ | IP67 - Dust Tight, Waterproof |
| VOLTAGE ILLUMINATION (НОМАҚ) | 5 ~ 28 VDC |
| НАВӢИ РАВШАН, РАНГ | LED, Green/Magenta |
| ВИЖАГИҶО | Finger Guide, T Symbol |
| ҶАӢТИ ЭЛЕКТР | - |
| ТАВСИФИ МУФАССАЛ | Pushbutton Switch SPST-NO Capacitive, Illuminated Panel Mount, Front |
| РЕЙТИНГҶОИ ҶОРӢ | 100mA (AC/DC) |
| РАНГИ - АКТУАТОР / КАП | Silver |
| РОҶБАРИЯТ | SPST-NO |
| НАМУДИ АМАЛКУНАНДА | Round, Button, Flush |

Садо Меҳмони "Озодӣ"

| | | |
|--|---|--|
| Schurter CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1020-S | Паҳнкунандаи CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1020-S | Таъминкунандаи CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1020-S |
| CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1020-S Напх | Суратҳои CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1020-S | Сурати CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1020-S |
| CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1020-S PDF маълумотнома | CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1020-S Боргирии маълумотҳо | Варақаи CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1020-S |
| CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1020-S саҳҳомӣ | CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1020-S харед | Schurter CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1020-S харед |
| Schurter CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1020-S | Таъминкунандаи Schurter | Паҳнкунандаи Schurter |
| Schurter CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1020-S | Schurter Inc. CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1020-S | |

Маҳсулотҳои марбута

| | |
|--|---|
|  <p>CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1021-S</p> <p>Истеҳсолкунандагон: Schurter Тавсифи: SWITCH PUSH SPST-NO 100MA 42V Дар фуруш: Out stock</p> <p>RFQ</p> |  <p>CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1017-S</p> <p>Истеҳсолкунандагон: Schurter Тавсифи: SWITCH PUSH SPST-NO 100MA 42V Дар фуруш: Out stock</p> <p>RFQ</p> |
|  <p>CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1016-S</p> <p>Истеҳсолкунандагон: Schurter Тавсифи: SWITCH PUSH SPST-NO 100MA 42V Дар фуруш: Out stock</p> <p>RFQ</p> |  <p>CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1014-S</p> <p>Истеҳсолкунандагон: Schurter Тавсифи: SWITCH PUSH SPST-NO 100MA 42V Дар фуруш: Out stock</p> <p>RFQ</p> |
|  <p>CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1015-S</p> <p>Истеҳсолкунандагон: Schurter Тавсифи: SWITCH PUSH SPST-NO 100MA 42V Дар фуруш: Out stock</p> <p>RFQ</p> |  <p>CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1023-S</p> <p>Истеҳсолкунандагон: Schurter Тавсифи: SWITCH PUSH SPST-NO 100MA 42V Дар фуруш: Out stock</p> <p>RFQ</p> |
|  <p>CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1025-S</p> <p>Истеҳсолкунандагон: Schurter Тавсифи: SWITCH PUSH SPST-NO 100MA 42V Дар фуруш: Out stock</p> <p>RFQ</p> |  <p>CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1019-S</p> <p>Истеҳсолкунандагон: Schurter Тавсифи: SWITCH PUSH SPST-NO 100MA 42V Дар фуруш: Out stock</p> <p>RFQ</p> |
|  <p>CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1024-S</p> <p>Истеҳсолкунандагон: Schurter Тавсифи: SWITCH PUSH SPST-NO 100MA 42V Дар фуруш: Out stock</p> <p>RFQ</p> |  <p>CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1026-S</p> <p>Истеҳсолкунандагон: Schurter Тавсифи: SWITCH PUSH SPST-NO 100MA 42V Дар фуруш: Out stock</p> <p>RFQ</p> |
|  <p>CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1022-S</p> <p>Истеҳсолкунандагон: Schurter Тавсифи: SWITCH PUSH SPST-NO 100MA 42V Дар фуруш: Out stock</p> <p>RFQ</p> |  <p>CPS16-NO00A10-SNCSNCWF-RI0GMVAR-W1018-S</p> <p>Истеҳсолкунандагон: Schurter Тавсифи: SWITCH PUSH SPST-NO 100MA 42V Дар фуруш: Out stock</p> <p>RFQ</p> |